

<div data-bbox="269 344 487 379" data-label="Section-Header"><h2>X Tag/Lineple</h2></div> <div data-bbox="269 409 471 656" data-label="Image"></div>	<div data-bbox="594 344 830 514" data-label="Text"><p>Model:X Tag/Lineple/Y12/Y14/Y17/Y29/Y27 Battery:CR2032 Voltage:DC 3V Wireless:BT 5.2 System:iOS Buzzer:Built-in ≥75db (in 10cm) Humidity range:≤95%(Non-condensing)</p></div> <div data-bbox="594 541 757 644" data-label="Text"><p>Warning: If the connection fails, 1.Click four times quickly. 2.Hold down the fifth time until hearing a ring tone. 3.Search for the link try again.</p></div> <div data-bbox="771 553 920 628" data-label="Image"></div>	<div data-bbox="975 323 1136 341" data-label="Section-Header"><h3>Quick instructions</h3></div> <div data-bbox="975 344 1226 384" data-label="Text"><p>1. Turn on the device and pair Press the function button once to turn it on, it should a ringing chime indicating it is powered on</p></div> <div data-bbox="1027 384 1188 453" data-label="Image"></div> <div data-bbox="975 462 1081 477" data-label="Section-Header"><h3>2. Pair the device</h3></div> <div data-bbox="975 480 1263 577" data-label="List-Group"><ul style="list-style-type: none">•Open the Find My app.•Hold the device close to your iPhone, iPad, tap the Items tab, tap + and then Add Other Item.•Tap Connect.•Type a name for your device, select an emoji.•Tap Agree to acknowledge that this item will be linked to your Apple ID.•Tap Finish.</div> <div data-bbox="975 582 1099 597" data-label="Section-Header"><h3>3. Enable Lost Mode</h3></div> <div data-bbox="975 598 1270 671" data-label="List-Group"><ul style="list-style-type: none">• Open the Find My app, tap the Items tab, then tap your item.• Under Lost Mode, tap Enable.• Read the instructions, tap Continue and enter a phone number or email address.• Confirm the information, customize the lost message, and tap Activate to complete the setup.</div>	<div data-bbox="1353 329 1481 344" data-label="Section-Header"><h3>4. Remove the device</h3></div> <div data-bbox="1353 346 1637 382" data-label="List-Group"><ul style="list-style-type: none">• Open the Find My app, tap the Items tab, then tap your item.• Tap Remove Item and then tap Remove to complete the operation.</div> <div data-bbox="1353 394 1651 482" data-label="Text"><p>Note: After removing the device in the app, if you want to pair it, you can open the Find My app and do it in 10 minutes. If there is no re-pairing within 10 minutes, the device will leave the pairing state and the device and app cannot be paired at this time. If you need to pair the device, you need to click the device button and the device will beep. At this point, the device enters the pairing state and can be re-paired with the app.</p></div> <div data-bbox="1353 491 1476 508" data-label="Section-Header"><h3>Main Functions</h3></div> <div data-bbox="1353 511 1465 526" data-label="Section-Header"><h4>1. Locate your item</h4></div> <div data-bbox="1353 527 1651 601" data-label="Text"><p>If your missing item isn't nearby, the Find My app can still help you track it down using the Find My network - hundreds of millions of iPhone, iPad, and Mac devices around the world. Nearby devices securely send the location of your missing device to iCloud, then you can see where it is in the Find My app. It's all anonymous and encrypted to protect everyone's privacy.</p></div> <div data-bbox="1353 616 1433 632" data-label="Section-Header"><h4>2. Play Sound</h4></div> <div data-bbox="1353 633 1639 669" data-label="List-Group"><ul style="list-style-type: none">• Open the Find My app, tap the Items tab, then tap your item.• Click Play Sound, and the device will beep, so you can find the item easily.</div>
<div data-bbox="235 709 510 734" data-label="Section-Header"><h3>How to connect Products?</h3></div> <div data-bbox="235 746 510 1014" data-label="Image"></div>	<div data-bbox="594 709 891 1038" data-label="Image"></div>	<div data-bbox="957 709 1256 1022" data-label="Image"></div> <div data-bbox="1136 893 1285 1034" data-label="Text"><p>Attention: For your safety, if you need to return and refund, please be sure to click the "remove item" option on the phone before returning it to avoid your privacy disclosure!</p></div>	<div data-bbox="1331 697 1660 994" data-label="Text"><p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.</p></div> <div data-bbox="1331 1014 1469 1040" data-label="Text"><p>Model:X Tag/Lineple/Y12 Y14/Y17/Y27/Y29</p></div> <div data-bbox="1510 988 1628 1055" data-label="Image"></div>